

DELTA® protects property. Creates comfort. Saves energy.

## DELTA®-MS UNDERSLAB INSTALLATION INSTRUCTIONS

### Health and Safety:

Required safety equipment: hard hat, safety boots, gloves, safety glasses.

- Always follow all safety precautions as directed by the Occupational Safety and Health Administration (OSHA-USA) or the Construction Safety Association (Canada).
- There are no health risks in using DELTA®-MS UNDERSLAB
- Please refer to Material Safety Data Sheets.
- The general codes of practice for protection at work and instructions of manufacturers for tool and components are to be observed at all times.

### Recommended Tools:

- Utility knife

### Getting Down to Installation:

- Roll out DELTA®-MS UNDERSLAB dimples facing down.
- Overlap the "flat tab" of DELTA®-MS UNDERSLAB located at one side of each roll, with the edge of the previous roll (see detail 1).
- Tape overlap seams with DELTA®-MULTI-BAND (see detail 2).
- At perimeter, cut DELTA®-MS UNDERSLAB as tightly as possible. If required use DELTA®-THAN permanently elastic sealant to fill all gaps (see detail 3).
- At service penetrations protruding from the floor cut DELTA®-MS UNDERSLAB as required as tightly as possible around penetrations.
- Tape around the protruding penetration using DELTA®-FLEXX-BAND (see detail 4).

### Clean-up and Inspection:

- Walk around perimeter and ensure all materials are installed as required.
- Clean up all excess materials.

For technical support, call the Technical Support Team at 1-888-4DELTA4 (1-888-433-5824) ext. 326 or [www.cosella-dorken.com](http://www.cosella-dorken.com)

